Please see the reverse side for English manual.

TOA

設置説明書

スピーカー壁取付金具　SR-WB3

ラインアレイスピーカーSR-H2L、SR-H2S、SR-H3L、およびSR-H3Sを壁に取り付けるための専用金具です。
スピーカーを壁面にぴったりと取り付けることができます。

■ 安全上のご注意

- ご使用の前に、この欄を必ずお読みになり正しくお使いください。
- ここに示した注意事項は、安全に関する重大な内容を記載していますので、必ず守ってください。
- お読みになったあとは、いつでも見られる所に必ず保管してください。

⚠ 警告　誤った取り扱いをすると、人が死亡または重傷を負う可能性が想定される内容を示しています。

設置場所の強度を確認する
スピーカーを含む全重量に十分耐えられる強度のある所に取り付けてください。
十分な強度がないと落下して、けがの原因となります。　強制

屋外に設置しない
本機は、屋内専用品です。
屋外に設置すると、部品の劣化により、機器が落下して、けがの原因となります。　禁止

指定方法以外の取り付けかたをしない
指定の取付方法を守らないと、無理な力がかかり、落下して、けがの原因となります。　禁止

適切なボルト、ナット類を使用する
壁の材質・構造に適したボルト、ナット類を使用してください。
守らないと、落下して、けがの原因となります。　強制

各部のボルト、ナット類は確実に締め付ける
取り付け後、ゆるみ、がたつきがあると、落下して、けがの原因となります。　強制

指定のスピーカーのみに使用する
守らないと、落下して、けがの原因となります。　強制

常に振動する場所に取り付けない
振動で金具が破損し、落下して、けがの原因となります。　禁止

⚠ 注意　誤った取り扱いをすると、人が傷害を負う可能性が想定される内容および物的損害のみの発生が想定される内容を示しています。

金属のエッジで手をこすらない
強くこすると、けがの原因となることがあります。　禁止

製品の上に乗らない
本機に乗ったり、ぶら下がったりしないでください。
倒れたり、落ちたりして、けがの原因となることがあります。　禁止

定期的な点検をする
販売店に、定期的な点検を依頼してください。
スピーカーまたは取付金具類の破損や腐食などにより、落下して、けがの原因となることがあります。　強制

■ 取り付けかた

1 壁側金具を壁に取り付ける。（右図参照）

2 スピーカー側金具をスピーカー本体の後面に取り付ける。
スピーカー後面の所定のねじを外し、そのねじ穴を使って取り付けます。
このとき、取り外したねじは使用しません。

メ　モ
スピーカー1台の場合は、金具をスピーカー後面の最上部と最下部の2カ所に、連結されたスピーカーの場合は、下図の位置に取り付けます。

3 スピーカー線を着脱式入力コネクターに接続する。
※ 接続のしかたは、適合スピーカーに付属の取扱説明書をお読みください。

4 スピーカー本体を壁側金具に引っ掛ける。
スピーカー側金具のフックの部分が、壁側金具の溝に挿入されるように、スピーカーを上から下にスライドさせて引っ掛けます。


5 固定ねじをスピーカー上部に取り付ける。
スピーカーが外れないように、スピーカー側金具と壁側金具を固定します。（連結時も同様です。）

連結時のスピーカー側金具の取付位置

SR-H3L を 2 台連結する場合
スピーカー側金具の員数：4 個
SR-WB3 の台数　：2 台

SR-H3L と SR-H2L を連結する場合
スピーカー側金具の員数：3 個
SR-WB3 の台数　：2 台

ご注意
スピーカー側金具は、1 個余ります。




■ 仕　様

適合スピーカー	SR-H2L、SR-H2S、SR-H3L、SR-H3S
仕　上　げ	圧延鋼板、ホワイト（マンセルN9.5近似色）、塗装
質　　量	220 g
構　成　品	スピーカー側金具 …… 2、壁側金具 …… 2
付　属　品	六角ボルトM4 × 15（座金付き）…… 1 六角ボルトM5 × 25（座金付き）…… 4
別　売　品	スピーカー連結金具：SR-EP3

※ 本機の仕様および外観は、改良のため予告なく変更することがあります。

壁側金具の取付寸法


SR-H2L を 1 台取り付ける場合	SR-H2S を 1 台取り付ける場合	SR-H3L を 1 台取り付ける場合	SR-H3S を 1 台取り付ける場合	SR-H3L と SR-H2L を連結して取り付ける場合	SR-H3L を 2 台連結して取り付ける場合
壁側金具の員数：2 個 SR-WB3 の台数：1 台	壁側金具の員数：2 個 SR-WB3 の台数：1 台	壁側金具の員数：2 個 SR-WB3 の台数：1 台	壁側金具の員数：2 個 SR-WB3 の台数：1 台	壁側金具の員数：3 個 SR-WB3 の台数：2 台	壁側金具の員数：4 個 SR-WB3 の台数：2 台



［壁側金具の寸法図］

単位：mm

ご注意
- 壁側金具は、天井面や障害物などから 70 mm 以上離して設置してください。
- SR-H3L と SR-H2L を連結する場合は、壁側金具は 1 個余ります。



⚠ 警告
壁に取り付けるためのボルト、ナット類は付属していません。
壁の材質・構造に適したボルト、ナット類を用意してください。

※ 図はスピーカー SR-H2L の取り付け例です。

商品の価格、在庫、修理およびカタログのご請求については、取扱い店または最寄りの営業所へお申し付けください。

TOAインフォメーションセンター
商品や技術など、お問い合わせにお応えします。
受付時間 9:00 ～ 17:00（日曜・祝日除く）

フリーダイヤル（無料電話）
TEL. 0120-108-117
〒665-0043 宝塚市高松町2番1号
TEL.（0797）72-7567
FAX.（0797）72-1090

TOAホームページ　http://www.toa.co.jp/

TOA株式会社

日本語の取扱説明書は裏面をご覧ください。

TOA **INSTALLATION MANUAL**

WALL MOUNTING BRACKET
SR-WB3

The SR-WB3 is a wall mounting bracket designed to install the Line Array Speaker SR-H2L, SR-H2S, SR-H3L, or SR-H3S flat against the wall.

1. SAFETY PRECAUTIONS

- Before installation or use, be sure to carefully read all the instructions in this section for correct and safe operation.
- Be sure to follow all the precautionary instructions in this section, which contain important warnings and/or cautions regarding safety.
- After reading, keep this manual handy for future reference.

⚠ WARNING

Indicates a potentially hazardous situation which, if mishandled, could result in death or serious personal injury.

- Install the unit only in a location that can structurally support the total weight of the unit and the speaker. Doing otherwise may result in the unit falling down and causing personal injury and/or property damage.
- Since the unit is designed for in-door use, do not install it outdoors. If installed outdoors, the aging of parts causes the unit to fall off, resulting in personal injury.
- Do not use other methods than specified to mount the bracket. Extreme force is applied to the unit and the unit could fall off, possibly resulting in personal injuries.
- Use bolts and nuts that are appropriate for the wall's material and structure. Failure to do so may cause the speaker to fall, resulting in material damage and possible personal injury.
- Tighten each nut and bolt securely. Ensure that the bracket has no loose joints after installation to prevent accidents that could result in personal injury.
- Use the unit only with the specified speaker. Doing otherwise may cause the unit to fall off, resulting in personal injury.
- Do not mount the unit in locations exposed to constant vibration. The mounting bracket can be damaged by excessive vibration, potentially causing the unit to fall, which could result in personal injury.

⚠ CAUTION

Indicates a potentially hazardous situation which, if mishandled, could result in moderate or minor personal injury, and/or property damage.

- Avoid touching the unit's sharp metal edge to prevent injury.
- Do not stand or sit on, nor hang down from the unit as this may cause it to fall down or drop, resulting in personal injury and/or property damage.
- Have the unit checked periodically by the shop from where it was purchased. Failure to do so may result in corrosion or damage to the unit that could cause the unit to fall, possibly causing personal injury.

2. INSTALLATION

Step 1. Install the Bracket bases to the wall.
(See the diagrams at right.)

Step 2. Attach the Speaker brackets to the speaker rear.
Remove the designated screws, then secure the brackets using these screw holes. The removed screws are not used.

Tip
For a single speaker, attach the brackets at the topmost and lowest positions on the speaker rear. For the linked speakers, attach them to the positions shown in the lower right diagram.


Step 3. Connect the speaker cable to the removable terminal plug.
For connection, refer to the instruction manual enclosed with the speaker.

Step 4. Hook the speaker on the Bracket bases.
Slide down the speaker body so that each Speaker bracket's hook fits in the Bracket base's slit.

Step 5. Fix the uppermost Speaker bracket with the supplied hex bolt M4 x 15.
This prevents the speaker from dropping off. (The same way applies to the linked speakers.)

Required number of Bracket bases and their mounting dimensions


Installing one SR-H2L	Installing one SR-H2S	Installing one SR-H3L	Installing one SR-H3S	Installing the linked SR-H2L and SR-H3L	Installing the linked 2 SR-H3Ls
2 Bracket bases (1 SR-WB3)	2 Bracket bases (1 SR-WB3)	2 Bracket bases (1 SR-WB3)	2 Bracket bases (1 SR-WB3)	3 Bracket bases (2 SR-WB3s)	4 Bracket bases (2 SR-WB3s)



[Dimensions of Bracket base]

Unit: mm (inches)

Notes
- Install the Bracket base at least 70 mm (3") away from the ceiling or any object.
- When installing the linked SR-H3L and SR-H2L, one Bracket base remains unused.




Note: This figure shows the installation example of the SR-H2L.

⚠ WARNING

Any bolts and nuts used to fix the Bracket base to the wall are not enclosed.
Prepare ones appropriate for the wall's material and structure.

Speaker bracket mounting positions when linking speakers



3. SPECIFICATIONS

Applicable Speaker	SR-H2L, SR-H2S, SR-H3L, SR-H3S
Finish	Rolled steel plate, white, paint
Weight	220 g (7.76 oz)
Component	Speaker bracket ... 2, Bracket base ... 2

Note: The design and specifications are subject to change without notice for improvement.

• Accessories
Hex bolt M4 x 15 (with washer) 1
Hex bolt M5 x 25 (with washer) 4

• Optional product
Extension Plate: SR-EP3

TOA Corporation

URL: http://www.toa.jp/

133-05-445-30